

We hope you will find these instructions helpful in setting up your product. If you have any issues with this item, **DO NOT** return the unit to place of purchase. Please visit our web site www.angelodecor.com for assistance and warranty information.



Carefully unpack and arrange all parts.



Locate the pre-installed tubing and attach it to the pump. Water flow can be adjusted using the control dial on the front of the pump.



Place the pump (with tubing attached) inside the fountain.



Locate and retrieve the light connection from inside the fountain. Securely attach the light to the transformer.



To prevent the risk of water loss, create a drip loop with the cables from the lights. Align the pump cord and light cables with the groove. Slide the pump access door in place.



Fill with clean water and plug into a grounded GFCI outlet.

The pump must be fully submersed at all times to avoid pump burnout.

This product must be dried and stored during freezing temperatures.

Nous espérons que vous trouverez ces instructions utiles en assemblant votre produit. Si vous avez n'importe quelles issues avec cet article, **ne renvoyez pas l'unité à l'endroit de l'achat**. Veuillez visiter notre site Web www.angelodecor.com pour l'information d'aide et de garantie.



Déballiez soigneusement et rangez toutes les pièces.



Trouvez le tuyau préinstallé et fixez-le à la pompe. Le débit d'eau peut être réglé à l'aide du cadran de commande situé à l'avant de la pompe.



Placez la pompe (avec le tube attaché) à l'intérieur de la fontaine.



Trouvez et récupérez la connexion lumineuse à l'intérieur de la fontaine. Fixez solidement la lumière au transformateur.



Pour éviter les risques de perte d'eau, créez une boucle d'égouttement avec les câbles des luminaires. Alignez le cordon de la pompe et les câbles d'éclairage avec la rainure. Faites glisser la porte d'accès à la pompe en place.



Remplissez d'eau propre et branchez dans une prise de mise à terre DDFT.

La pompe doit être entièrement submersée à tout moment pour éviter d'endommager la pompe.

Ce produit doit être séché et stocké pendant des températures glaciales.